



# **GEN4 PRO XTREME BigComm Pro Transmission Menu User Manual**

[www.BigStuff3.com](http://www.BigStuff3.com)

## HOW TO USE THE BIGCOMM PRO CONFIGURATION & CALIBRATION TOOL BAR TRANSMISSION CONTROL MENU AND SUBMENU



The GEN4 ECU's transmission control feature will allow you to control either a General Motors 4L60E or 4L80E transmission. The first true GM electronic transmission was the 4L80E, introduced in 1991 and the 4L60E followed the 4L80E in 1993.

Computer-controlled transmissions have changed automatics forever. Just as fuel injection has made the engine more powerful, functional, and reliable, the electronic transmission outperforms and outlasts any of its predecessors.

This is an optional feature to the GEN4 and must be enabled in order to use this functionality. If in your current project the Transmission Icon is not available the ECU does not currently support it. Contact BigStuff for more details on how to enable this feature.

### Transmission Control - System Contents

The transmission control option is sold with this user's manual and the standalone transmission wire harness, shown below.

The remaining transmission control functionality is contained within the GEN4 ECU when it is ordered with the transmission control option.

GEN4 ECUs sold with the transmission control option will have two (2) header connectors one at each end of the ECU (vs. one header connector for the fuel and spark only ECUs).



**It is essential that the transmission wire harness main connector be installed in the correct header connector location on the ECU!**

**Installing the transmission [Harness Main Connector](#) to the incorrect header location on the GEN3 ECU will damage the ECU and void the warranty!!**

The header connector at one end of the GEN4 ECU will be marked "Transmission" to indicate the header location where the transmission wire harness must be connected to.

### • **SYSTEM INSTALLATION OVERVIEW**

The BigStuff3 transmission control wire harness was designed to connect directly to the stock GM input and output shaft speed sensors and the stock 20-pin header connector on the transmission.

The steps required to configure the GEN4's transmission control feature are described in detail in this manual. A brief overview of the installation and configuration process is described below.

1. **Install the BigStuff3 Transmission Wire Harness** - Install the transmission wire harness between the GEN4 ECU and the transmission. The wire harness installation process is very straightforward. There are a total of 5 connections that need to be made, as outline below:
  - Two (2) connections to the **Transmission Input (TISS)** and **Output (TOSS) Sensors**. These connections are made directly with the stock sensors on the transmission.
    - i. Note: 4L60E transmissions only have a TOSS sensor.*
  - One (1) connection to the stock 20-pin connector on the transmission.
  - The transmission wire harness header connector to the GEN4 ECU header connector marked "Transmission".
  - The +12v Switched wire connection.
2. **Configure the ECU** for the transmission being used.
3. **Configure the Operating Tables** – Specifically, the **Shift, Torque Converter Clutch (TCC)** and **Line Pressure (LP)** tables.

### • **TRANSMISSION WIRE HARNESS INSTALLATION**

To improve the overall wire harness installation process, the transmission wire harness was manufactured with identification labels at the end of each wire or connector to ensure that connections are properly made.



The transmission wire harness has two halves; one half is intended to be located inside the vehicle, with the ECU, the other half connects to the sensors on the transmission.

The two halves of the harness are separated by a firewall grommet (see photo) designed to fit snugly in a 2-1/8" hole, which needs to be located in the firewall.

The best location for the firewall hole is in an unobstructed location, on the side of the passenger compartment closest to where the ECU will be mounted.

Care should be taken not to locate the grommet hole too far from the transmission. Doing so may affect the wire lengths that connect to the sensors on the transmission.

Some initial layout investigations should be made before the grommet hole is made in the vehicle sheet metal.

The paragraphs below describe how and where each connection should be made.

Hyperlinks (underlined, re wording) in the column titled "Further Details" were included to further assist with the transmission wire harness installation. Left clicking the PC's mouse on the hyperlink will immediately link to a photo of the connector along with additional installation information.

Harness Label	Wire Color / Connector Type	Label Definition	Connect To	Further Details
TISS	Black 2-way Packard Connector with blue Seal	Transmission Input (shaft) Speed Sensor	See <a href="#">TISS Sensor Connection</a>	See <a href="#">TISS Sensor</a> . <b>Only 4L80E transmissions have TISS sensors!</b>
TOSS	Black 2-way Packard Connector with blue Seal	Transmission Output (shaft) Speed Sensor	See <a href="#">TOSS Sensor Connection</a>	See <a href="#">TOSS Sensor</a>
+12V Switch	Single pink wire	Switched 12V supply input	Connect to a 12V source that is "live" when the ignition key is in the "start" position	See <a href="#">Twelve Volt Switched</a>
4L60E/4L80E Trans	Gray 20-Pin Connector	Main harness side connector to the transmission	See <a href="#">Twenty Pin Connector Connection</a>	Directly below this table
Wire Harness Main Connector	Black 30-Way Connector	N/A	GEN3 ECU Header Connector Marked "Transmission"	See <a href="#">Harness Main Connector</a>
Harness Label	Wire Color / Connector Type	Label Definition	Connect To	Further Details
Transmission Valve Body Fuse	N/A	N/A	N/A	<a href="#">Valve Body Fuse</a>

**20-Pin Transmission Header Connector**



Connect the harness side 20-Pin connector to the stock 20-Pin header connector on the transmission.

The location on the transmission where this termination should be made can be seen by clicking on [Twenty Pin Connector Connection](#).

**INPUT AND OUTPUT SHAFT SENSORS**

The **Trans Input (shaft) Speed Sensor (TISS)** and **Trans Output (shaft) Speed Sensor (TOSS)** measure the input and output speeds of the transmission so the GEN4 ECU can determine when to lock the converter, how much slip to allow with an unlocked converter, the vehicle load, the shift pressure, and the vehicle speed. The TISS and TOSS sensor connectors are identical in shape and color. It is important to make sure these connections are made to the correct speed sensor on the transmission. Terminating these connectors to the wrong transmission sensor will impact transmission operation and could damage the ECU, thus voiding the warranty.

## TISS Sensor

Terminate this connector to the stock (TISS) speed sensor on the 4L80E transmission.

*Note: The 4L60E transmission does not have a TISS sensor!*

The location on the transmission where this termination should be made can be seen by clicking on [TISS Sensor Connection](#).

[BACK TO TISS SENSOR](#)

## TOSS Sensor

Terminate this connector to the stock speed (TOSS) sensor on the transmission. The location on the transmission where this termination should be made can be seen by clicking on [TOSS Sensor Connection](#).


[BACK TO TOSS SENSOR](#)

## 12V Switched (single pink wire)

A secure connection must be made to a switched 12V supply. The best and in most cases the only source of a switched 12V supply is at the vehicle fuse block. The ECU must have a "live" 12V supply during cranking. If the 12V supply does not stay live, during cranking, the ECU will not function.

A simple way to determine if a live 12V supply exists during cranking is to check it with an inexpensive voltmeter. Securely fasten the voltmeter's red (+ positive) wire to the ignition input on the fuse block. Secure the voltmeter's black wire (- negative) to a ground location on the fuse block or another adequate location. Once the voltmeter connections are made, crank the engine. The voltage meter should indicate an output voltage of between 8V to 14 volts. If the output voltage is below 8 volts, check to make sure the battery is fully charged and all the cells of the battery are functioning properly.

**Note:** If a battery with both 12V and 16V cells is being used, the switched ignition (Vsw) **must** be tied to the same voltage rail as the main battery connections are connected to. Do not connect the ECU main cables to the 16V rail and have Vsw connected to +12V. **This will damage the ECU and void the warranty!**



### Wire Harness Main Connector

The 30-way harness side main connector mates with the GEN4 ECU header connector marked with "Transmission".

This connector will only fit in one direction, but must be mated with the ECU header connector marked "Transmission".


**Note:** *It is essential that the transmission wire harness main connector be installed in the correct header connector location on the ECU! Installing the transmission harness main connector to the incorrect header location on the GEN4 ECU will damage the ECU and void the warranty!*




### Valve Body 15-Amp Fuse

This fuse protects the transmission valve body.

[BACK TO VALVE BODY FUSE](#)




### 4L80E Transmission Wire Harness Connection Points Illustration



## • **TRANSMISSION SOFTWARE CONFIGURATION**

The transmission pulldown menu is where the transmission tables are stored to configure and program the 4L60E/4L80E transmission.



**(1)** Transmission Configuration – This section is where the base transmission settings are programmed.

**(2)** Shift Curves Bigcomm View – The shift tables used to configure the gear up and down shifts.

**(3)** Shift Curves Up/Down View – Optional table used to configure the shift tables. We recommend using the Bigcomm view shift curve tables.

**(4)** Torque Converter Clutch Curves – The TCC curves is used to configure when the torque converter locks and unlocks in third and fourth gear.

**(5)** Line Pressure Curves – The curves used to establish how hard the transmission upshifts

**THIS AREA LEFT BLANK INTENTIONALLY**



## • TRANSMISSION CONFIGURATION

- (1) **Trans Control** - When enabled, 4L60/80E trans functions, when disabled have alternate functions for TCC, FRCMTR, and Soln\_A.
- (2) **Gearbox Type** - Choose which automatic transmission you will be using.
- (3) **Number of gears** - Enter how many total gears the transmission will be using.
- (4) **MPH Calc Variables** - Enter the rear gear ratio and rear tire diameter in inches.
- (5) **Torque Converter Control** - More Info below this section.
  - a. TCC Rate (mS) - Rate of TC Lockup
  - b. TCC Delay (Sec) - TC Lockup Delay
  - c. TCC Min MPH - TC Min MPH to lockup.
- (6) **Line Pressure** - More info below in this section.
  - a. Reduction in LP DC in Reverse - The amount of line pressure reduction when going into Reverse.
- (7) **Shift Time** - The value used by the ECU to determine the minimum time between successive up-shifts and down-shifts.
- (8) **Engine Braking Gear Downshift MPH** - The values used by the ECU to determine when to downshift gears to assist in slowing vehicle down.

## • TORQUE CONVERTER CONTROL

Section 5 above in the transmission configuration section is used to adjust how the torque converter operates while the transmission is in use.

**TCC Rate (mS)** - TCC Rate is the rate at which the torque converter lockup is applied. The larger the number inputted, the quicker the converter clutch will be "locked". A number like 255 will lock the converter very quickly. A number like 128 will lock the converter at a much slower rate. It is better to start with a lower value, gradually increasing the number until the desired clutch lock rate is achieved.

**TCC Delay (Sec)** - The TCC Delay is the time between when the following criteria are met and




when the torque converter begins to lockup. Delay Criteria = Minimum throttle position (for idle) is exceeded by the TPS%. Note: the torque converter is unlocked if the throttle is closed. Vehicle Speed = Vehicle speed has to exceed the value set in the TCC table. Transmission Fluid Temperature = This variable is "hard coded" at the factory.

**TCC Min MPH** – Below this MPH, Torque Converter Clutch will unlock when throttle is below Max TPS for Idle calibration.


***Shift Curves Bigcomm View***

The shift table is used to configure transmission up-shifts and down-shifts for each gear as a function of vehicle speed (MPH) and percent (%) throttle opening. The green lines in the windows above represent transmission up-shift points and the red lines represent the down-shift points. The area between the red and green lines is the hysteresis needed to keep the transmission from continually up-shifting or down-shifting. The below pictures are examples of shift curves for gears 1-4. Click on each gear curve to expose the shift table to adjust.


***1st Gear Curve***




### 2<sup>nd</sup> Gear Curve



### 3<sup>rd</sup> Gear Curve



### 4<sup>th</sup> Gear Curve



### • TORQUE CONVERTER CLUTCH CURVES

As you will notice, there are only two windows in the **Torque Converter Clutch (TCC)** table. This is because the converter is only allowed to “Lock-up” in third and fourth gear (with a 4-speed transmission) and fourth and fifth gear (with a 5-speed transmission).

The TCC table is used to configure when the torque converter locks and unlocks in third and fourth gear (with a 4-speed transmission) as a function of vehicle speed (MPH) and percent (%) throttle opening.

The **green** line in the windows above represents the points when the torque converter begins to lockup, based on settings in the [Torque Converter Control](#) section of the Transmission Configuration table. The **red** line represents the points when the torque converter unlocks.


The area between the red and green lines is the hysteresis needed to keep the transmission from continually locking and unlocking.

When the ECU is powered and the wheels are moving, an ellipse will appear in the “active” window representing the current vehicle speed and throttle position. When the ellipse moves above the **green** line, the torque converter begins to lock, and when the ellipse moves below the **red** line the torque converter will unlock.


The ECU does not allow the converter to remain locked during a gear shift.



### 4<sup>th</sup> Gear Torque Converter Clutch Curve



### 3<sup>rd</sup> Gear Torque Converter Clutch Curve




### • LINE PRESSURE CURVES


The **Line Pressure (LP)** table is used to configure transmission line pressure (up-shift firmness) for each gear as a function of percent (%) throttle opening.

There is an inverse relationship between the force motor duty cycle % and line pressure. In other words, the lower the percent (%) duty cycle, the higher the line pressure and the higher the percent (%) duty cycle value the lower the line pressure, and the less firm the gear shift will be. See the example line pressure curves for each gear below.

#### 1<sup>st</sup> Gear Line Pressure Curve




#### 2<sup>nd</sup> Gear Line Pressure Curve






### 3<sup>rd</sup> Gear Line Pressure Curve




### 4<sup>th</sup> Gear Line Pressure Curve





## • SOFTWARE VIEWING

In the Bigcommpro software navigate to the Gauge Cluster tab beneath the System Menu Icon. In the lower right-hand corner click on the 4L60\_80E\_Trans tab. This tab will display the current automatic transmission information and is useful for watching all data pertaining to the automatic transmission controls.



## FREQUENTLY ASKED QUESTIONS

### • What does working "On line" vs. "Off line" mean?

-Working "Off-line" = The BigStuff3 ECU is not powered up (PC Only). Working "On-line" = The BigStuff3 ECU is powered on, the communication is connected between the GEN4 ECU and a PC, and the two are communicating with each other

### • Should I use the camshaft position input (cam sync) with my distributor based GEN4 system?

-Without the camshaft position input (cam input connector in the main wire harness) hooked up, the GEN4 system still provides sequential fuel injection and individual fuel control per cylinder, but injector phasing (where the fuel is injected) and individual spark control will not function.

### • How can the GEN4 system provide sequential fuel injection and individual fuel control per cylinder without the cam camshaft position input hooked up?

-When the engine starts cranking over, the GEN4 ECU begins firing the injector drivers, assigned to each injector, in the firing order inputted into the software. What the GEN3 system cannot do without the cam camshaft position input hooked up is to determine where to inject fuel (the position in crankshaft degrees, relative to TDC, for each cylinder).

The Base Spark Table(s) are edited as soon in the Bigstuff3 GEN4 ECU Full Software Manual

located on our website. Click on this link to navigate and download.

- **At what injector duty cycle % are my injectors considered out of control, or static?**

-Loss of injector control does not occur at 100% duty cycle, but at approximately 85% duty cycle. At 85% duty cycle the injectors are most likely not opening and closing in a controlled fashion.

-This condition is termed "static" (vs. dynamic) control. An example why this condition is undesirable is if the GEN4 ECU demands more fuel (demanding a larger pulse width) and the injector is already static. The only way to move more fuel through the injector would be to increase the fuel pressure. Increasing the fuel pressure at the 1/8th mile marker is not possible, so things go bad quickly.

-Also, teetering on and off at the static point is also undesirable. Lastly, running the injectors drivers static for long periods of time can damage them.

- **How do I set up my ignition system with the GEN4 system?**

-For more information on ignition system setups, beyond what is available in this manual, go to the How To/Help section on the BigStuff3 website, and then Ignition System Setup Tutorial. The link is: <http://bigstuff3.com/pdf/ignition%20Guide%20rev%201.2.pdf>. There are nine (9) ignition system setups outlined. There is also information on the setting up the Ford TFI, GM HEI, GM Opti-spark & MSD8 ignition systems in the How To/Help section of the website.

- **Where can I find wiring harness information on the BS3 power-train system and optional systems?**

-Information on most of our wiring harnesses is available on our website at [www.bigstuff3.com](http://www.bigstuff3.com).

-Go to the GEN4 section on the website and under the GEN4 PRO XTREME menu will be more information. The link is: <http://bigstuff3.com/gen4/>

- **My engine will not start. What should I check?**

-Make sure the harness side header connectors, interfacing with the GEN4 ECU, are attached and tightened to no more than 15 – 20 inch lbs.

-Make sure the battery voltage is at, or above, 12V during cranking. Low battery voltage conditions must be fixed before trying to start the engine. Battery voltage (especially during cranking) is even more important with coil-on-plug applications.

-Make sure you can see an RPM signal in the software or dash. While turning the engine over, you should see at least 100 – 150 RPM. If no RPM signal is present, check that the crank input (crank trigger or distributor) signal wire is connected to the red wire in the BS3 "Crank" connector. Swap the 2 wires and try again.

-For distributor ignition based applications, make sure the BS3 points wire is connected to the ignition system points input terminal/wire. Applying 12V directly to the BS3 points wire will immediately damage the GEN4 ECU!!

-For COP engines (LSx and other standalone COP engine) the cam input cannot occur at the

same time as the crank input!!! If this is the case, the engine will not start. The cam synch pulse must occur before a crank pulse. Ideally, 10\* before the crank pulse.

-For more information on ignition system setups, go to the How To/Help section on the BS3 website, then to Ignition System Setup Tutorial.

-With all coil-on-plug engines, make sure the coil ground eyelet is securely fastened to the cylinder head or engine block. No other grounds locations should be used.

-The ECU may be in Clear flood Mode. Make sure the TPS sensor reads near 1-2% when the throttle is closed and near 100% when fully opened. If it reads near 100% when closed, the ECU is in clear flood mode and is not injecting fuel. Swap TPS pins A & C in the TPS connector.

Make sure the crank sensor is connected.

-The LS1 Cam sensor connections are: **• A - Signal • B - Ground • C - 12V •**

The LS2 cam sensor connections must be (terminals A & C are swapped): **• A - 12V • B - Ground • C - Signal**

**• My engine timing does seem right, what should I check.**

-Make sure the firing order is correct.

-Both the BS3 GEN4 main wiring harness and the MSD ignition system must be connected directly to the battery!! If not, ground loop issues are likely to occur.

-Make sure your pulses per rev in the Operating Configuration table is correct for your application. For example, a four (4) magnet MSD crank trigger setup should have a value of 4.

**• I can't get my LSx engine started.**

-I'm using an LS2 sensor in the front of the engine.

-Swap pins A & C in the cam input connector around. My TPS sensor reads 100% when the throttle is closed and 0% when the throttle is fully opened. Swap the wires A & C in the TPS connector. The engine may not start since the ECU senses that the Clear flood Mode has been invoked

**• If I am tuning in Alpha/N mode (Hardware Configuration, then Control Algorithm) can I use my 1 Bar MAP sensor for barometric compensation?**

-Yes, the automatic barometric compensation is hard-coded in the ECU. Leave the MAP sensor vacuum port exposed to the atmosphere. Do not plug the MAP vacuum port to the intake manifold.

**• What do I need to do to make sure my 3 step works correctly?**

-A clean 12VDC must be applied to Header 2 W1 meaning a relay with only 12vdc. Do not use the same 12VDC feeding the transbrake solenoid as flyback voltage from the transbrake releasing can damage the ECU!

-Confirm the 3 Step settings in the System Menu / RevLimiters are configured correctly. The TPS% On threshold must be higher than the Off threshold.

**• I do not think my injectors are pulsing. What can I check?**

-Make sure the BS3 and MSD systems are grounded directly to the battery.

-Plug a "noid" light into each injector position in the injector wire harness. Turn the engine over and see if the light pulses for each injector location.

• **I do not think my COP coils are firing. What can I check?**

-Make sure the BS3 main wire harness ground is wired directly to the battery.  
 -Make sure the coil ground wire is grounded to the engine block or cylinder head. No other ground location will work!

• **Can I use a 5 Bar MAP sensor?**

-Yes, choose 5 Bar MAP sensor in the System Menu / Pressure and Sensor Configuration section.  
 -Be sure to cycle the 12VDC ignition on the ECU and you will need to recalibrate the fuel/afr/spark tables on this or any MAP sensor change.  
 - Note: The 4 BAR MAP sensor sold by BigStuff3 is good to 52 PSI.

• **How do I know if my Bosch LSU4.9 WBO2 sensor is bad?**

-First make sure the sensor to main wire harness connection is good.

• **How can I check if my NTK WBO2 Methanol sensor is working?**

-First check the control circuitry by disconnecting the sensor from the harness. Turn the ignition to the BS3 ECU on. With the engine off its best to move the O2 sensor out of the exhaust and have it hang in the air. Go online with the ECU and navigate to the Gauge Cluster tab and go to the NTKWBO2 tab on the bottom the screen. In the upper right hand corner of the page will be LB%O2 and RB%O2 readings. Go to the AFR Menu and click on the O2 and EGT Parameters section. In the lower right hand corner turn the "Perform NTKO2 WBO2 Air Cal" to "Yes".

**WARNING!** Do not hold the O2 sensor as it will start to heat up and you can get severely burned. You will see the O2% readings start to update and after about 5 minutes you should be reading about 18%-22% on either sensor. If you do not read that more than likely the sensor is defective and needs to be replaced. Contact Bigstuff3 for more details at this point. If the sensor reads fine turn the Air Cal to "Off" and turn the ignition off. Wait for the sensor to cool down and reinstall in the exhaust and you are ready to go.

• **What caused my O2 sensor to fail?**

-Being dropped  
 -Running leaded fuel  
 -Running rich at idle

• **Does the GEN4 ECU offer an auto-shift feature?**

Yes, BigStuff3 offers an optional transmission auto-shift feature. The system will shift up to five (5) speeds with independent shift RPM and Hysteresis points. Once the system is configured for the auto-shift feature, a wire from ECU Header 2 location, P2 must be run to the ground side of the relay.

• **What dwell times should be used with the LS1 coils sold with my system?**



With a 12V charging system from idle to approximately 4,000 RPM use about 3.0 milliseconds near idle and no more than about 4.0 milliseconds at approximately 4,000 RPM. From approximately 4,100 - Max RPM use no more than about 6 milliseconds of total dwell time at max RPM. With a 16V charging system from idle to approximately 4,000 RPM use about 2.0 milliseconds near idle and no more than about 3.0 milliseconds at approximately 4,000 RPM. From approximately 4,100 - Max RPM use no more than about 4.5 milliseconds of total dwell time at max RPM.

Datalogger acronyms

Point Definitions are displayed in alphabetical order and are the same for either laptop based datalogging or pulling the data from the on board SD card.

## **A**

**AC\_BUMP\_ON** – Air Conditioning Engine RPM increase active condition

**ACCEL\_X** – Accelerometer X Axis

**ACCEL\_Y** – Accelerometer Y Axis

**ACCEL\_Z** – Accelerometer Z Axis

**ACCEL\_ENG** – Acceleration Engine value

**ACT\_IAC\_POS** – Current Idle Air Control Motor Position

**AFR\_TARGET** – Air Fuel Ratio Target

**AFR\_L\_BANK** – Air Fuel Ratio Left Bank

**AFR\_R\_BANK** – Air Fuel Ratio Right Bank

**AFR\_CYL\_1** – Air Fuel Ratio Cylinder 1

**AFR\_CYL\_2** – Air Fuel Ratio Cylinder 2

**AFR\_CYL\_3** – Air Fuel Ratio Cylinder 3

**AFR\_CYL\_4** – Air Fuel Ratio Cylinder 4

**AFR\_CYL\_5** – Air Fuel Ratio Cylinder 5

**AFR\_CYL\_6** – Air Fuel Ratio Cylinder 6

**AFR\_CYL\_7** – Air Fuel Ratio Cylinder 7

**AFR\_CYL\_8** – Air Fuel Ratio Cylinder 8

## **B**

**BARO** – Outside Barometric Pressure

**BATTERY\_VOLTAGE** – Battery voltage

**BC\_SENSOR\_ERROR** – Boost Controller Sensor Input Error

**BOOST\_PSI** – Intake Manifold Pressure

**BOOST\_CL\_DC** – GN Boost Controller Duty Cycle Output %

**Boost\_Inc PIDTerm** – GN Boost Controller PID Increase %

**C**

**CLT** – Coolant Temperature  
**CORR\_AIR** – Fuel Percentage Air Temperature Correction  
**CORR\_AFTST** – Afterstart Fuel Percentage Correction  
**CORR\_BARO** – Barometric Fuel Percentage Correction  
**CORR\_CLT** – Coolant Warm Up Temperature Fuel Percentage Correction  
**CORR\_E85** – E85 Fuel Percentage Correction  
**CORR\_ES\_PVFC** – Extended Source Power Valve Fuel Correction Percentage  
**CORR\_FP\_COMP** – Fuel Pressure Correction  
**CORR\_PVF** – Power Valve Fuel Correction  
**CORR\_SLT** – Start Line Fuel Percentage Correction

**D**

**DAE\_INPUT** – DAE 12vdc Input true or false  
**DSRD\_BOOST\_MAP** – Desired Boost Map  
**DSRD\_SR2\_MAP** – Desired SR2 Map  
**DUTY\_CYCLE\_BOOST\_INC** – Boost Controller Duty Cycle Output Increase %  
**DUTY\_CYCLE\_BOOST\_DEC** – Boost Controller Duty Cycle Output Decrease %  
**DUTY\_CYCLE\_PWM07** – Duty Cycle Output Pulse Width Modulation 07  
**DUTY\_CYCLE\_PWM08** – Duty Cycle Output Pulse Width Modulation 08  
**DUTY\_CYCLE\_PWM09** – Duty Cycle Output Pulse Width Modulation 09  
**DUTY\_CYCLE\_NOS\_PRG** – Progressive Nitrous Duty Cycle Control Output Percentage  
**DUTY\_CYCLE\_CYL1** – Fuel Injector Duty Cycle Percentage Cylinder 1  
**DUTY\_CYCLE\_CYL2** – Fuel Injector Duty Cycle Percentage Cylinder 2  
**DUTY\_CYCLE\_CYL3** – Fuel Injector Duty Cycle Percentage Cylinder 3  
**DUTY\_CYCLE\_CYL4** – Fuel Injector Duty Cycle Percentage Cylinder 4  
**DUTY\_CYCLE\_CYL5** – Fuel Injector Duty Cycle Percentage Cylinder 5  
**DUTY\_CYCLE\_CYL6** – Fuel Injector Duty Cycle Percentage Cylinder 6  
**DUTY\_CYCLE\_CYL7** – Fuel Injector Duty Cycle Percentage Cylinder 7  
**DUTY\_CYCLE\_CYL8** – Fuel Injector Duty Cycle Percentage Cylinder 8  
**DUTY\_CYCLE\_FRCMTR** – Duty Cycle Force Motor Output Percentage (Used with 4L60E/80E)  
**DUTY\_CYCLE\_TCC** – Duty Cycle Torque Converter Clutch Output (Used with 4L60E/80E)  
**DWELL\_TIME** – Ignition Coil Dwell Time

**E**

**E85\_SPARK\_OFFSET** – E85 Spark Offset  
**ECM\_RB\_EC** – NTK O2 Sensor Right Bank Error Code  
**ECU\_SYNC** – Current ECU Synchronization Status  
**EGT\_CYL1** – Exhaust Gas Temperature Cylinder 1  
**EGT\_CYL2** – Exhaust Gas Temperature Cylinder 2



**EGT\_CYL3** – Exhaust Gas Temperature Cylinder 3  
**EGT\_CYL4** – Exhaust Gas Temperature Cylinder 4  
**EGT\_CYL5** – Exhaust Gas Temperature Cylinder 5  
**EGT\_CYL6** – Exhaust Gas Temperature Cylinder 6  
**EGT\_CYL7** – Exhaust Gas Temperature Cylinder 7  
**EGT\_CYL8** – Exhaust Gas Temperature Cylinder 8  
**ENG\_STATE** – Engine State (1-Engine Cranking, 4-Engine Running Steady, 5-Engine Accelerating, 6-Engine Decelerating, 7-Deceleration Fuel Cutoff)  
**EGT\_SHUTDOWN\_ACTIVE** – Exhaust Gas Temperature Shutdown Active Condition  
**ETM\_TORQ\_STG** – Engine Torque Management Torque Stage Current Value  
**ETM\_DS\_ENG\_ERROR** – ETM Driveshaft or Engine RPM Error  
**ETM\_DS\_ENG\_DSRD** – ETM Driveshaft or Engine RPM Desired

## **F**

**FP\_SENSOR\_ERROR** – Fuel Pressure Sensor Input Error  
**FP\_WARNING\_ACTIVE** – Fuel Pressure Warning Active Condition  
**FSL\_TBL\_INDEX** – Fuel Spark Lambda current map enabled  
**FUEL\_FLOW\_CYL1** – Calculated Fuel flow in lbs/hr for Cylinder 1  
**FUEL\_FLOW\_CYL2** – Calculated Fuel flow in lbs/hr for Cylinder 2  
**FUEL\_FLOW\_CYL3** – Calculated Fuel flow in lbs/hr for Cylinder 3  
**FUEL\_FLOW\_CYL4** – Calculated Fuel flow in lbs/hr for Cylinder 4  
**FUEL\_FLOW\_CYL5** – Calculated Fuel flow in lbs/hr for Cylinder 5  
**FUEL\_FLOW\_CYL6** – Calculated Fuel flow in lbs/hr for Cylinder 6  
**FUEL\_FLOW\_CYL7** – Calculated Fuel flow in lbs/hr for Cylinder 7  
**FUEL\_FLOW\_CYL8** – Calculated Fuel flow in lbs/hr for Cylinder 8  
**FUEL\_FLOW\_TOTAL** – Total Calculated Fuel Flow of cylinders 1-8 in lbs/hr

## **G**

**GEAR** – Current Gear position calculated by engine rpm drop  
**GEN\_BOOST\_ADD** – Generic Boost Tables Additional Boost Pressure  
**GEN\_FUEL\_LBSHR\_ADD** – Generic Fuel Lbs/hr adder  
**GEN\_FUEL\_MULT** – Generic Fuel Multiplier Percentage Adder  
**GEN\_LAMBDA\_ADD** – Generic Lambda Fuel Adder  
**GEN\_LAMBDA\_MULT** – Generic Lambda Fuel Multiplier  
**GEN\_SPK\_ADV\_ADD** – Generic Spark Advance Adder  
**GS\_ACCEL** – Gear Speed Acceleration  
**GYRO\_X** – Gyrometer X Axis  
**GYRO\_Y** – Gyrometer Y Axis  
**GYRO\_Z** – Gyrometer Z Axis

## H

**HEAD\_TEMP\_RB** – Head Temperature Right Bank. When in Pro Mod Mode located in the System->Hardware Configuration section this sensor is enabled for use. Pro Mod Mode sets the water and air sensors to 100\* in the software so that they have no bearing on the overall VE fuel calculation. This is the GM Water Temperature Sensor.

**HEAD\_TEMP\_LB** – Head Temperature Left Bank. When in Pro Mod Mode located in the System->Hardware Configuration section this sensor is enabled for use. Pro Mod Mode sets the water and air sensors to 100\* in the software so that they have no bearing on the overall VE fuel calculation. This is the GM Air Temperature Sensor.

## I

**IAT** – Intake Air Temperature

**ICF\_CORR\_CYL1** – Individual Cylinder Fuel Percentage Correction Cylinder 1

**ICF\_CORR\_CYL2** – Individual Cylinder Fuel Percentage Correction Cylinder 2

**ICF\_CORR\_CYL3** – Individual Cylinder Fuel Percentage Correction Cylinder 3

**ICF\_CORR\_CYL4** – Individual Cylinder Fuel Percentage Correction Cylinder 4

**ICF\_CORR\_CYL5** – Individual Cylinder Fuel Percentage Correction Cylinder 5

**ICF\_CORR\_CYL6** – Individual Cylinder Fuel Percentage Correction Cylinder 6

**ICF\_CORR\_CYL7** – Individual Cylinder Fuel Percentage Correction Cylinder 7

**ICF\_CORR\_CYL8** – Individual Cylinder Fuel Percentage Correction Cylinder 8

**ICS\_CORR\_CYL1** – Individual Cylinder Spark Correction Cylinder 1

**ICS\_CORR\_CYL2** – Individual Cylinder Spark Correction Cylinder 2

**ICS\_CORR\_CYL3** – Individual Cylinder Spark Correction Cylinder 3

**ICS\_CORR\_CYL4** – Individual Cylinder Spark Correction Cylinder 4

**ICS\_CORR\_CYL5** – Individual Cylinder Spark Correction Cylinder 5

**ICS\_CORR\_CYL6** – Individual Cylinder Spark Correction Cylinder 6

**ICS\_CORR\_CYL7** – Individual Cylinder Spark Correction Cylinder 7

**ICS\_CORR\_CYL8** – Individual Cylinder Spark Correction Cylinder 8

**INJ\_GPW\_AVE** – Fuel Injector Gross Pulse Width Average

**INJ\_PHASE\_ANGLE** – Fuel Injector Injection Event Phase Angle

**IOT** – Fuel Injector Opening Tim

## L

**LAMBDA\_CYL1** – Lambda Value Cylinder 1

**LAMBDA\_CYL2** – Lambda Value Cylinder 2

**LAMBDA\_CYL3** – Lambda Value Cylinder 3

**LAMBDA\_CYL4** – Lambda Value Cylinder 4

**LAMBDA\_CYL5** – Lambda Value Cylinder 5

**LAMBDA\_CYL6** – Lambda Value Cylinder 6

**LAMBDA\_CYL7** – Lambda Value Cylinder 7



**LAMBDA\_CYL8** – Lambda Value Cylinder 8  
**LAMBDA\_L\_BANK** – Lambda Reading Left Bank  
**LAMBDA\_R\_BANK** – Lambda Reading Right Bank  
**LAMBDA\_TARGET** – Lambda Reading Left Bank  
**LAMBDA\_RB\_UA** – Lambda Right Bank NTK O2 Error Code  
**LASER\_HEIGHT\_AD5** – Laser Height Sensor Reading

## M

**MAP** – Engine Intake Manifold Pressure  
**MPH** – Miles Per Hour

## N

**NERNST\_CYL1** – Resistance value of the Cylinder 1 Bosch O2 sensor. Normal value is around 300. **NERNST\_CYL2** – Resistance value of the Cylinder 2 Bosch O2 sensor. Normal value is around 300.  
**NERNST\_CYL3** – Resistance value of the Cylinder 3 Bosch O2 sensor. Normal value is around 300.  
**NERNST\_CYL4** – Resistance value of the Cylinder 4 Bosch O2 sensor. Normal value is around 300.  
**NERNST\_CYL5** – Resistance value of the Cylinder 5 Bosch O2 sensor. Normal value is around 300.  
**NERNST\_CYL6** – Resistance value of the Cylinder 6 Bosch O2 sensor. Normal value is around 300.  
**NERNST\_CYL7** – Resistance value of the Cylinder 7 Bosch O2 sensor. Normal value is around 300.  
**NERNST\_CYL8** – Resistance value of the Cylinder 8 Bosch O2 sensor. Normal value is around 300.  
**NOS\_STAGE** – Current NOS Stage  
**NOS\_BOOST\_ENABLE** – Nitrous or Boost Enable Arm Switch  
**NOS\_TIMER** – When activated is the Nitrous Run Time  
**NOS\_ICS\_CORR\_CYL1** – Nitrous Individual Cylinder Spark Correction Cylinder 1  
**NOS\_ICS\_CORR\_CYL2** – Nitrous Individual Cylinder Spark Correction Cylinder 2  
**NOS\_ICS\_CORR\_CYL3** – Nitrous Individual Cylinder Spark Correction Cylinder 3  
**NOS\_ICS\_CORR\_CYL4** – Nitrous Individual Cylinder Spark Correction Cylinder 4  
**NOS\_ICS\_CORR\_CYL5** – Nitrous Individual Cylinder Spark Correction Cylinder 5  
**NOS\_ICS\_CORR\_CYL6** – Nitrous Individual Cylinder Spark Correction Cylinder 6  
**NOS\_ICS\_CORR\_CYL7** – Nitrous Individual Cylinder Spark Correction Cylinder 7  
**NOS\_ICS\_CORR\_CYL8** – Nitrous Individual Cylinder Spark Correction Cylinder 8

## O

**O2\_CORR\_CYL1** – Closed Loop O2 AFR Fuel Correction Cylinder 1  
**O2\_CORR\_CYL2** – Closed Loop O2 AFR Fuel Correction Cylinder 2  
**O2\_CORR\_CYL3** – Closed Loop O2 AFR Fuel Correction Cylinder 3  
**O2\_CORR\_CYL4** – Closed Loop O2 AFR Fuel Correction Cylinder 4  
**O2\_CORR\_CYL5** – Closed Loop O2 AFR Fuel Correction Cylinder 5  
**O2\_CORR\_CYL6** – Closed Loop O2 AFR Fuel Correction Cylinder 6  
**O2\_CORR\_CYL7** – Closed Loop O2 AFR Fuel Correction Cylinder 7  
**O2\_CORR\_CYL8** – Closed Loop O2 AFR Fuel Correction Cylinder 8  
**O2\_CORR\_L\_BANK** – Closed Loop O2 AFR Fuel Correction Left Bank  
**O2\_CORR\_R\_BANK** – Closed Loop O2 AFR Fuel Correction Right Bank

## P

**PCT\_ETHANOL** – Percentage of Ethanol in fuel (Need sensor to read properly)  
**PEDAL\_BIT\_MODE** – Pedal Bit Mode Current Condition  
**PCT\_TCC\_SLIP** – Percentage of Torque Converter Clutch Slippage (Used with 4L60E/80E)  
**PRESS\_FUEL** – Fuel Pressure Reading  
**PRESS\_OIL** – Oil Pressure Reading  
**PRESS\_TURBO** – Turbocharger Pressure Reading  
**PRESS\_WG** – Wastegate Pressure Reading  
**PRESS\_NOS** – Nitrous Pressure Reading  
**PRESS\_PV** – Pan Vacuum Reading  
**PRESS\_TL** – Transmission Line Pressure Reading  
**PRESS\_DSRD\_WG** – CO2 Desired Wastegate  
**PRNDL** – Park / Reverse / Neutral / Drive / Low (Used with 4L60E/80E)

## R

**RACE\_FUEL\_LBS\_HR** – NOS Mode Race Fuel Lbs/hr fuel adder  
**REV\_LIMITER** – Current condition of any active rev limiters  
**RPM\_ENGINE** – Engine RPM  
**RPM\_TSS1\_LB** – Turbocharger Shaft Speed RPM Left Bank  
**RPM\_TSS2\_RB** – Turbocharger Shaft Speed RPM Right Bank  
**RPM\_ABS\_FW** – RPM Front Wheel Speed Sensor  
**RPM\_ABS\_RW** – RPM Rear Wheel Speed Sensor  
**RPM\_TOSS** – RPM Transmission Output Speed Sensor or Driveshaft Sensor  
**RPM\_TISS** – RPM Transmission Input Speed Sensor

## S

**SLT\_MODE** – Start Line Timing Mode Current Condition

**SHOCK\_RF\_AD7** – Right Front Shock Reading  
**SHOCK\_LF\_AD8** – Left Front Shock Reading  
**SHOCK\_RR\_AD9** – Right Rear Shock Reading  
**SHOCK\_LR\_AD10** – Left Rear Shock Reading  
**SPK\_ADV\_BCP** – Base Spark Advance  
**SPK\_ADV\_CYL1** – Spark Advance Cylinder 1  
**SPK\_ADV\_CYL2** – Spark Advance Cylinder 2  
**SPK\_ADV\_CYL3** – Spark Advance Cylinder 3  
**SPK\_ADV\_CYL4** – Spark Advance Cylinder 4  
**SPK\_ADV\_CYL5** – Spark Advance Cylinder 5  
**SPK\_ADV\_CYL6** – Spark Advance Cylinder 6  
**SPK\_ADV\_CYL7** – Spark Advance Cylinder 7  
**SPK\_ADV\_CYL8** – Spark Advance Cylinder 8  
**SR2\_TIMER** – Current Race time after the release of the three step  
**SR2\_GEAR1\_SPK\_OFFSET** – SR2 Gear 1 Spark Offset  
**SR2\_DS\_SPK\_OFFSET** – SR2 Driveshaft or Engine Spark Offset  
**SR2\_DS\_ERROR** – SR2 Driveshaft or Engine RPM Error  
**SR2\_DS\_DSIRD** – SR2 Driveshaft or Engine RPM Desired  
**SS\_SPK\_NOS\_RTD** – Street Strip Nitrous Spark Retard  
**SS\_NOS\_FUEL\_ADD** – Street Strip Nitrous Fuel Adder  
**SS\_NOS\_LAMBDA\_OFFSET** – Street Strip Nitrous Lambda Target Offset

## **T**

**TPS** – Throttle Position Sensor Percentage  
**TOT** – Transmission Oil Temperature Reading  
**THREE\_STEP\_INPUT** – Three Step Input 12vdc true or false  
**THREE\_STEP\_MODE** – Three Step Active Condition  
**TRANS\_GEAR\_RATIO** – Current Transmission Gear Ratio (Used with 4L60E/80E)  
**TSD\_GEAR1\_OFFSET** – Touch Screen Dash Gear 1 Offset  
**TSD\_SR2\_DS\_OFFSET** – Touchscreen Dash SR2 Driveshaft or Engine RPM Offset  
**TSD\_ETM\_DS\_OFFSET** – Touchscreen Dash ETM Driveshaft or Engine RPM Offset  
**TWO\_STEP\_INPUT** – Two Step Input 12vdc true or false  
**TWO\_STEP\_ACTIVE** – Two Step Active Condition  
**TWO\_STEP\_MODE** – Two Step Active Condition

## **V**

**VE** -Volumetric Efficiency number calculated from the base fuel map

# W

**WHEEL SPIN** – Calculated wheel speed based off differential from either the rear wheel speed sensor or driveshaft sensor compared to the front wheel speed sensor.

©2022 BigStuff3 | Phone: (650) 678-2434 | Web: [www.BigStuff3.com](http://www.BigStuff3.com)